



PLIDCO® TAP+ENCLOSURE DOMED WELD-ON STYLE INSTALLATION INSTRUCTIONS

LANGUAGES:

CLICK ON LANGUAGE DESIRED

ENGLISH

SPANISH



The Pipe Line Development Company
11792 Alameda Drive, Strongsville, Ohio 44149, USA
Phone: (440) 871-5700 • Fax: (440) 871-9577
Toll Free: 1-800-848-3333
web: www.plidco.com • e-mail: pipeline@plidco.com

PLIDCO® TAP+ENCLOSURE Domed Weld-On Style INSTALLATION INSTRUCTIONS

If you have any questions, or encounter any difficulties using this product, please contact: PLIDCO 440-871-5700

READ CAREFULLY

The person in charge of the repair must be familiar with these instructions and communicate them to all personnel involved in the repair crew.

Installation

1. The domed style PLIDCO Tap+Enclosure can be used to encase items attached to a pipeline other than just a tap branch.
2. Dependent on the pipe size and your company's purchase requirements, the domed style Tap+Enclosure may or may not have been supplied contoured to fit the pipe. It may be required to contour the weld cap in the field.
3. Only use weld procedures approved by your company.
4. Remove the pipe plug from the domed style Tap+Enclosure before welding. This eliminates pressure build-up inside the Tap+Enclosure while welding.
5. Hold the Tap+Enclosure on the pipe over the obstruction to be encased and tack weld it to the pipeline.
6. To complete, weld the Tap+Enclosure to the pipe using an approved weld procedure.
7. After welding completely, the PLIDCO Tap+Enclosure can be pressure tested through the vent hole to prove a seal weld if required.
8. Insert the pipe plug in the vent hole and seal weld if required.



SPANISH INSTRUCTIONS
COMING SOON